


Life Cycle 90C
General Assembly

90C-0XXX-01


S/N LCA100001




Description	Part No.
Polar Upgrade Kit	GK63-00002-0002
Accessory Tray	GK63-00002-0004

Life Cycle 90C
Console Assembly

90C-0XXX-01
S/N LCA100001





Console Assembly	Overlay Bezel
AK63-00162-0001 Eng Met	AK63-00167-0001 Eng Met
AK63-00162-0003 Ger Met	AK63-00167-0003 Ger Met
AK63-00162-0004 Spn Met	AK63-00167-0004 Spn Met
AK63-00162-0007 Frn Met	AK63-00167-0007 Frn Met
AK63-00162-0008 Itl Met	AK63-00167-0008 Itl Met
AK63-00162-0009 Dut Met	AK63-00167-0009 Dut Met
AK63-00162-0010 Por Met	AK63-00167-0010 Por Met



Life Cycle 90C
Crank Shaft and Bearings

90C-0XXX-01
S/N LCA100001




Life Cycle 90C
Intermediate Shaft and Bearings

90C-0XXX-01
S/N LCA100001

Clutch Assembly
AK63-00026-0000
(not included in kit)


Magnet
118E-00001-0124
(not included in kit)






Life Cycle 90C
Seat Latch Assembly


90C-0XXX-01
S/N LCA100001

Seat Latch Assembly
AK63-00043-0001













Console Support Assembly
AK63-00067-0001












Front Wheel Assembly
AK63-00017-0001





Resistor Assembly
AK63-00114-0000




Handlebar Assembly
AK63-00101-0001






Power control Cable
AK63-00098-0000



CONTROL



UPPER CONSOLE

UPPER KEYPAD